

MADE⁺

Wall Clock Instructions


PLEASE READ THESE INSTRUCTIONS CAREFULLY & RETAIN FOR FUTURE REFERENCE

ACTIVATING THE CLOCK

Insert 1 x AA (1.5V) battery into the battery compartment located on the back of the clock taking care to observe the correct polarity. (Battery not included)

TIME SETTING

To set the clock to the desired time, rotate the 'hand set knob' until the correct time is reached.



FIXING INSTRUCTIONS

When attaching the clock to the wall please ensure that you use a screw and wall fixing suitable for the size and weight of the clock.

1. Use a large screw and wall fixing suitable for your wall.
2. Drill a suitable sized hole to insert the wall plug.
3. Gently tap wall plug into drilled hole.
4. Insert screw into the wall plug, leaving the screw protruding slightly.
5. Hang clock onto the protruding screw, taking care to ensure clock and screw are mated correctly.

Care Instructions

- Wipe clock with a soft dry cloth only.
- Replace battery when the clock stops.

Battery safety & disposal

- Dispose of batteries responsibly at a local authority household waste recycling facility.
- **DO NOT dispose of batteries in a fire as the batteries may explode or leak.**
- **Only use** 'AA' 1.5V batteries in this clock.
- Never use rechargeable batteries.
- For products using more than one battery, please ensure all batteries are replaced at the same time.
- Never try to dismantle batteries.
- Never short circuit batteries.
- Exhausted batteries must be removed from the clock promptly.
- Remove batteries from the product before extended storage.



This symbol  indicates that this product, and any batteries, should not be disposed of in normal household waste but taken to appropriate local recycling centres, where available.